


# Wonder Gun

## SS Type

W301-III-LC · W301-III-LH

W301-III-TC · W301-III-TH

W301-III without hose joint



① Body  
④ O Ring

② O Ring  
⑤ Set Column

③ Suction Nozzle

### <How to assemble>

Above-mentioned number, from ①,②,③,④,⑤ is for blow off operation.

For suction operation, please attach suction nozzle ③ to the right and left in reverse direction shown as above 3qat assembly.

Please attach the dust collector or bag during suction operation to prevent the sucked in materials from hitting a person or subjects as it may cause serious damage to human body / life.

### <How to use>

For suction operation, please induce the main air jet and the compressed air simultaneously. In case of connecting the air hose at the suction side, attaching a short hose is preferred. Depending on the transfer distance, please connect guns in a row of 2 or 3 for optimum performance.

For 2 guns connection, combination with regular type and powerful type is available. Please inquire for the combination.



**DANGER**

Please do a thorough read prior to the operation.

- Please attach the dust collection bag during suction to prevent the sucked in materials from hitting a person or subjects, or it may cause serious damage to human body / life.
- Please be careful with the scattered materials when blowing. Please wear protection glasses while operating to prevent loss of eyesight, or the scattered materials may hit your eyes.
- Do not use this device on a human body.
- Do not suck anything considered as dangerous in general situation.
- Do not misuse as it might cause serious damage to human body / life.

**CAUTION**

- Please push the seal tape LIGHTLY into the hose joint while attaching the nipple to avoid breaking the service screw. The air hose joint is designed for tapered screw to attach air hose.
- Use with the air pressure gauge under 0.9MPa (9kg/cm<sup>2</sup>).
- Do not use beside ears. It may cause hearing disorder because of the exhaust noise.
- In case of using this device for adsorption, please test well whether the device adsorbs well since this is not designed for that purpose.
- This device is not suitable for liquid suction since it may lead to mist getting mixed with the air. The compressed air might get mixed with the sucked in materials when passing through this device at the suction. Please use SILENT CLEANER for liquid suction.
- Do not use this device except for suction, blow off, or transfer.
- Use with the temperature under 40°C.
- Keep out of reach from children.
- In case you have question about the usage, stop operation immediately and inquire the manufacturer.

\* Please keep this caution note at a place where operator can easily read at anytime.

 **OSAWA & COMPANY**

1-7-28, Yunagi, Minato-ku, Osaka 552-0004 Japan  
TEL: +81-6-6572-1207 FAX: +81-6-6572-1256  
URL: <http://www.osawa-company.co.jp>  
E-mail: [osawa@osawa-company.co.jp](mailto:osawa@osawa-company.co.jp)